

Installation Instructions for use of the FG 103 Post Driver



1. Place Delineator Post into Driver



2. Position Anchor at Location



3. Grasp the Handles and Slide Up & Down



4. Repeat Process Until Anchor is at Least 2" (5cm) below ground.



FG 500 Post Properly Installed